


A3101 Touchscreen Programmable Thermostat



APPLICATION

The A3101 Touchscreen Programmable Thermostat is an effortless, 7-Day programmable thermostat that provides universal system compatibility, precise comfort control and is easy to program.

The A3101 Thermostats provide temperature control for gas, oil, electric and heat pump for 1 and 2 stage systems including dual fuel operation.

FEATURES

- Large, clear display with backlight shows the current and set temperature and thermostat in the dark.
- Menu-driven programming make setup effortless.
- Beautiful ergonomic design is smart and sophisticated to match your customers lifestyle.
- Touchscreen interaction
- Real-time clock keeps time during power failures and automatically updates to daylight savings.
- "Saving Changes" notification lets you know when the schedule changes have been saved.
- Change/check reminders let you know when to service or replace filters or batteries
- Various Hold options allow you to override the program schedule, as desired.
- Armchair programming allows you to remove the thermostat from the wall for programming.

SPECIFICATIONS

Thermostat Description:

Feature	Description
Powering methods	Common wire with battery backup
System types (1 heat/1 cool)	• Gas, oil or electric heat with air conditioning • Warm air, hot water, high-efficiency furnaces, heat pump without auxiliary heat, steam and gravity • Heat only includes power to open and power to close zone valves and normally-open zone valves • Heat only with fan • Cool only • 750 mV heating systems
Changeover	Manual or Auto changeover selectable
System setting	HEAT-OFF-COOL-AUTO
Fan setting	AUTO-ON-CIRC

4

A3101 Touchscreen Programmable Thermostat

Electrical Ratings:

Terminal	Voltage (50/60 Hz)	Running Current
W Heating	20 - 30 VAC	1 AMP max.
W Heating (Power pile)	750 mVDC	100 mAMP
Y Cooling	20 - 30 VAC	1 AMP max.
G Fan	20 - 30 VAC	1 AMP max.

Temperature Setting Range:

Heating: 40°F to 90°F (4°C to 32°C).

Cooling: 50°F to 99°F (10°C to 37°C).

Operating Ambient Temperature:

32°F to 120°F (0°C to 49°C).

Shipping Temperature:

A3101 Thermostats: -30 °F to 150 °F
(-34.4°C to 65.6°C).

5

Operating Relative Humidity (Non-condensing):

A3101 Thermostats: 5% to 90%.

Cycle Rates (at 50% Load):

Heating: Selectable 1 - 12 cycles per hour.

Cooling: Selectable 1 - 6 cycles per hour.

Clock Accuracy: +/- 1 minute per month.

Batteries:

Two replaceable AA alkaline batteries will power the thermostat when 24VAC common is not used. A non-replaceable lithium battery with ten-year life is inside the thermostat. Under normal use the lithium battery will maintain the calendar and time settings. The Alkaline batteries maintain the calendar and time after lithium battery is no longer functional.

Cool Indication:

A3101 Touchscreen Thermostats show "Cool On" on the screen when Cool is activated.

Heat Indication:

A3101 Touchscreen Thermostats show "Heat On" on the screen when Heat is activated.

Calibration:

A3101 Touchscreen Thermostats are factory-calibrated and require no field calibration.

INFORMATION

If you have additional questions, need further information, or would like to comment on our products or services, please write or phone:

A3101 Touchscreen Programmable Thermostat

Nomenclature:

Series	System Stages	Application
A3101	1H/1C	A3101 - Standard

Mounting Means:

A3101 Touchscreen Thermostat: Mounts directly on the wall in the living space using mounting screws and anchors provided.

Outdoor Sensor: Mounts outside of living space with mounting clip and screws provided.

Remote Indoor Sensor: Mounts directly on the wall using mounting screws and anchors provided.

Dimensions:

1. A3101 Touchscreen Thermostat: see Fig 1.
2. A3101 Touchscreen Thermostat Back Case: see Fig. 2
3. A3101 Outdoor Sensor Mounting Clip: see Fig 3.
4. A3101 Cover Plate: see Fig 4.




Fig. 1. Touchscreen Thermostat dimensions in inches. (mm).

10




Fig. 2. Touchscreen Thermostat Back Case dimensions in inches. (mm).

11




Fig. 3. Outdoor Sensor Mounting Clip dimensions in inches. (mm).




Fig. 4. Cover Plate dimensions in inches. (mm).

INSTALLATION

When Installing this Product...

1. Read these instructions carefully. Failure to follow the instructions can damage the product or cause a hazardous condition.
2. Check the ratings given in the instructions to make sure the product is suitable for your application.
3. Installer must be a trained, experienced service technician.
4. After completing installation, use these instructions to check out the product operation.

Selecting Location

Install the thermostat about 5 ft. (1.5m) above the floor in an area with good air circulation at average temperature. See Fig. 5.

Do not install the thermostat where it can be affected by:

- Drafts or dead spots behind doors and in corners.
- Hot or cold air from ducts.
- Radiant heat from sun or appliances. Concealed pipes and chimneys.
- Unheated (uncooled) areas such as an outside wall behind the thermostat.

14




Fig. 5. Selecting thermostat location.

15

Installing Wallplate



CAUTION

Electrical Hazard.

Can cause electrical shock or equipment damage.
Disconnect power before wiring.

The thermostat can be mounted horizontally on the wall

1. Position and level the wallplate (for location only).
2. Use a pencil to mark the mounting holes.
3. Remove the wallplate from the wall and, if drywall, drill two holes in the wall, as marked. For firmer material such as plaster, drill two holes. Gently tap anchors (provided) into the drilled holes until flush with the wall.
4. Position the wallplate over the holes, pulling wires through the wiring opening. See Fig. 6
5. Insert the mounting screws into the holes and tighten.




Fig. 6. Mounting wallplate.

WIRING (FIG. 9 - 16)

All wiring must comply with local and national electrical codes and ordinances.

1. Select set of terminal identifications (Table 1) that corresponds with system type (conventional or heat pump in Fig. 7).
2. Loosen the screws for the appropriate system type selected; see Table 1. See Table 2 for terminal designation descriptions. Insert wires in the terminal block under the loosened screw. See Fig. 8.
3. Securely tighten each screw.
4. Push excess wire back into the hole.
5. Plug the hole with nonflammable insulation to prevent drafts from affecting the thermostat.
6. See Fig. 9 through 16 for typical wiring hookups.




Fig. 7. Selecting terminal identifications for system type.

Table 1. Selecting Terminal Identifications for System Type.

System Type	Wallplate Terminal Identifications	Wiring Diagram Reference
Standard Heat/Cool	Conventional	9, 10
Heat Only	Conventional	11
Heat Only with Fan	Conventional	12
Heat Only Power to open and power to close zone valves	Conventional	13
Normally Open Zone Valves Heat Only	Conventional	14
Cool Only	Conventional	15
Heat Pump without auxiliary heat	Heat Pump	16




Fig. 8. Inserting wires in terminal block.


IMPORTANT: Use 18 gauge thermostat wire.

Table 2. Terminal Designation Descriptions.

Terminal Designation	Description
RC (see Note 1)	Power for cooling—connect to secondary side of cooling system transformer
R (see Note 1)	Power for heating—connect to secondary side of heating system transformer
C (see Note 2)	Common wire from secondary side of cooling system transformer
W	Heat relay
Y	Compressor contactor
G	Fan relay
O/B (see Note 3)	Changeover valve for heat pump system
L (see note 4)	Equipment monitor for heat pump system
S1, S2	Optional outdoor or indoor remote sensor

NOTES:


1. When used in a single-transformer system, leave metal jumper wire in place between RC and R. If used on a two-transformer system, remove metal jumper wire between RC and R.
2. Common wire is optional when thermostat is used with batteries.
3. If thermostat is configured for a heat pump system in the Installer Setup, configure changeover valve for cool (O-factory setting) or heat (B).
4. The "L" terminal is an input (system monitor) when the System mode is in the HEAT, OFF, COOL or AUTO position. When using the "L" terminal connect the 24 VAC Common. See LCD indications on page 81.



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. FACTORY INSTALLED JUMPER.
3. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 9. Typical hookup of conventional single-stage heat and cool system with single transformer(1H/1C conventional).


22



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.
3. REMOVE FACTORY INSTALLED JUMPER.

Fig. 10. Typical hookup of conventional single-stage heat and cool system with two transformers (1H/1C conventional).


23



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. FACTORY INSTALLED JUMPER.
3. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 11. Typical hookup of heat-only system (1H conventional).


24



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. FACTORY INSTALLED JUMPER.
3. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 12. Typical hookup of heat only system with fan (1H conventional).


25



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. FACTORY INSTALLED JUMPER.
3. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 13. Typical hookup of heat only power to open and power to close zone valve system.

26



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. FACTORY INSTALLED JUMPER.
3. OPTIONAL OUTDOOR OR INDOOR REMOTE SENSOR. AVAILABLE ON SELECT MODELS. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 14. Typical hookup of heat only system with normally open zone valves.

27




Fig. 15. Typical hookup of cool only system(1C conventional).

28




Fig. 16. Typical hookup of single-stage heat pump without auxiliary/backup heat (1H/1C heat pump).

29

POWER THE THERMOSTAT

You can choose from three methods to power the thermostat.

- Batteries only (AA alkaline).
- 24VAC common wire only.
- 24VAC common wire with battery backup (AA alkaline).

Wiring 24VAC Common

- Single-Transformer System:

Connect the common side of the transformer to the C screw terminal of the thermostat wallplate. Leave the metal jumper wire in place between RC and R.

- Two Transformer System:

Connect power side of "Cooling" transformer to RC terminal. Remove factory installed jumper. Connect common side of "Cooling" transformer to the compressor contactor, relay, etc. Connect power side of "Heating" transformer to the R terminal. Connect the common side of the Heat relay to the C terminal.

30

Installing Batteries

1. Install Two AA alkaline batteries on the back of the thermostat as marked on the thermostat. See Fig. 17.

2. Locate and remove the tab. See Fig. 18.

BATTERIES(2)




Fig. 17. Installing batteries.

REMOVE
- TAB




Fig. 18. Remove tab.

31

Mount Thermostat to Wallplate

1. Align the terminal screw blocks with the pins on the back of the thermostat. Push the thermostat straight onto the wallplate until it snaps into place. See Fig 19.




Fig. 19. Mount thermostat to wallplate.

32

Locate and Mount Outdoor Temperature Sensor (Optional)

Mount the sensor where:

- the ceilings cannot be tampered with.
- there is good air circulation.
- it can measure true outdoor ambient temperature.
- there is a flat surface.

• maximum distance between outdoor sensor and touchscreen thermostat is 65 ft (20m).
See fig 20.

Do not mount the sensor

- in direct sunlight.
- where hot or cold air blows on the sensor. Discharge line from an outdoor compressor unit, vent or fan causes inaccurate temperature readings.
- where snow, ice or debris can cover it.

Use the following steps to mount the sensor:

1. Remove the sensor from the mounting clip.
2. Mark the area on the location selected for mounting the sensor mounting clip.
3. Mount the clip.

33




Fig. 20. Typical locations for ORS-1 Outdoor Sensor.

34

⚠ CAUTION- OUTDOOR SENSOR

Electrical Interference (Noise) Hazard.

Can cause erratic system operation.

Keep wiring at least one foot away from large inductive loads such as motors, line starters, lighting ballasts and large power distribution panels.

Use shielded cable to reduce interference when rerouting is not possible.

IMPORTANT

Erratic temperature readings from a sensor can occur as a result of any of the wiring practices that are not to local and national electrical standards. Follow wiring these practices to assure correct operation. Use shielded cable to reduce interference if rerouting sensor wiring is not possible.

35



CAUTION- OUTDOOR SENSOR

Electrical Shock Hazard.

Can cause electrical shock or equipment damage.

Disconnect power supply before connecting wiring.

Wiring must comply with local and national codes, ordinances and regulations:

1. Wire Outdoor Sensor to S1 and S2 terminals on the thermostat. If leadwire provided is not long enough, you need an extra cable to reach the hole at maximum distance between the outdoor sensor and the touchscreen thermostat is 65ft (20m).

a. Using color-coded, 18-gauge thermostat wire is recommended. For example of general wiring of sensor, see Fig. 21.

b. Pigtail wiring can be used.

2. Mount Sensor in its mounting clip.

3. Plug wiring hole using non-hardening caulk or putty.

3. Plug wiring hole using non-hardening caulk or putty.


Be sure wires have a cable separate from the thermostat cable.

Do not route temperature sensor wiring with building power wiring, next to control contactors or near light dimming circuits, electric motors or welding equipment.

Avoid poor wiring connections.

Avoid intermittent or missing building earth ground.

36



1. USE APPROPRIATE MOUNTING MEANS FOR THE TYPE OF STRUCTURE.
2. PLUG WIRING HOLE WITH NON-HARDENING CAULK OR PUTTY.

Fig. 21. Wire Outdoor Sensor to the thermostat.

37

Locate and Mount Remote Indoor Temperature Sensor (Optional)

1. Choose a location (see Fig. 22) for mounting the sensor on an inside wall about 5 ft (1.5m) above the floor.
2. Be sure wire distance between sensor and thermostat is less than 19.6 ft (6m).
3. Make sure there is good air circulation at average temperature at the chosen location. Avoid the following locations because they can introduce errors in sensor measurements. See Fig. 22.
 - Hot areas caused by:
 - (a) Concealed pipes or ducts.
 - (b) Drafts from fireplaces or other heat sources.
 - (c) Convection or radiant heat from the sun or electrical equipment.
 - Cold areas caused by:
 - (a) Concealed pipes or ducts.
 - (b) Drafts from windows and doors.
 - Unheated areas on the other side of the wall location.
 - Dead air areas:
 - (a) Behind doors, furniture and curtains. (b) In corners and alcoves.
4. Mark the area on the wall selected for mounting the Sensor or junction box.
5. Run wire cable to a hole at the selected wall location. Pull approximately three inches of wire through the opening. Color-coded, 18-gauge thermostat wire is recommended.

38




Fig. 22. Typical location for Indoor Sensor.

39

Wire Indoor Sensor



CAUTION

Electrical Interference (Noise) Hazard. Can cause erratic system operation.
Keep wiring at least one foot away from large inductive loads such as motors, line starters, lighting ballasts and large power distribution panels.

IMPORTANT

Erratic temperature readings from a sensor can occur as a result of any of the wiring practices described below. Avoid these practices to assure correct operation.

Be sure wires have a separate cable from the thermostat cable.

Do not route temperature sensor wiring with building power wiring, next to control contactors or near light dimming circuits, electric motors or welding equipment.

Avoid poor wiring connections.

Avoid intermittent or missing building earth ground.

40


WARNING

**Can cause electrical shock or equipment damage.
Disconnect power supply before connecting wiring.**

Wiring must comply with local and national codes, ordinances and regulations.


- 1. Wire Indoor Sensor to S1 and S2 terminals on the thermostat.** For an example of general wiring of IRS-1, see Fig. 23 to wire one sensor and 24 to wire multiple sensors.
- 2. Push excess wire back into the hole.** Plug the hole using non-hardening caulk, putty or insulation to prevent drafts from affecting performance.
- 3. Remove IRS-1 sensor cover.**
- 4. Mount IRS-1 to the wall or junction box using the screws and anchors provided.**
- 5. Level IRS-1 for appearance only.** Device functions correctly even when not level.
- 6. Install IRS-1 cover.**

41



1. POWER SUPPLY. PROVIDE DISCONNECT MEANS AND OVERLOAD PROTECTION AS REQUIRED.
2. IF MORE THAN ONE REMOTE SENSOR IS REQUIRED, REFER TO FIGURE 24.
3. WIRES MUST HAVE A CABLE SEPARATE FROM THE THERMOSTAT CABLE.

Fig. 23. Wiring a single Indoor Sensor.





1. SENSORS MUST BE ARRANGED IN THIS CONFIGURATION TO OPERATE CORRECTLY.
2. WIRES MUST HAVE A CABLE SEPARATE FROM THERMOSTAT CABLE.

Fig. 24. Wiring Multiple Sensors.

42


1. Press and release the SYSTEM Key.

2. Press and hold the two blank keys on either side of the center blank key for approximately five seconds until screen changes.




43

3. Release the two blank keys when the screen on the thermostat matches the screen below.



4. See screen below to review how the thermostat keys are used during Installer Setup. See Tables 3-5 for the Installer Setup Numbers and Settings.



5. Press the DONE key to exit the Installer

44

Installer Setup Menu

The following table lists the Installer Setup menu options and the "TABLE SETTING RECORD" column.

Table Setting Record	Installer Setup Menu	Settings	Status	Table Setting Record
0120	Date Year Upper	Select last two digits of current calendar year (25 for year 2001-2099)	It cannot be changed	
0130	Date Year Lower	Select last two digits of current calendar year (00 for year 2000, etc.)	2001 - 2099 available	
0140	Date Month	Select number that represents current calendar month		
0150	Date Day	Select number that represents current calendar date		
0160	Schedule Options	0-nonprogrammable 4-7-day programmable	When it is changed, the Schedule must be reprogrammed.	
0170	System Type Selection	1-1 heat/1 cool conventional (factory setting) 2-single-stage heat pump (no auxiliary heat) 3-heat only conventional (no fan) Also for 750mV. 4-heat only conventional (with fan) 5-heat only (power to open and power to close zone valves or normally-open zone valves) 6-cool only conventional	Available options and defaults vary by thermostat. System selection automatically modifies some default settings and/or hides other Installer Setup options.	

45

Table 3. Installer Setup Menu.(CONTINUED)

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0180	Fan Control in Heating	0-gas or oil furnace equipment controls fan in heating (factory setting) 1-electric furnace thermostat controls fan in heating	Only shown if conventional system is selected. If heat pump is chosen, fan defaults to electric.	
0190	Changeover Valve O/B Terminal Energized in Heating or Cooling (Heat Pumps Only)	0-changeover valve O/B terminal is energized in cooling. 1-changeover valve O/B terminal is energized in heating.	Only shown if heat pump system is chosen.	
0200			NOT USED	
0210			NOT USED	
0220	Cycles per hour (cph) for 1st Stage Compressor	3-cph recommended for compressors (factory setting) 1, 2, 4, 5, 6-other cycle rate settings		
0230			NOT USED	

Table 3. Installer Setup Menu. (CONTINUED)

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0240	Cycles per hour (cph) for 1st Stage Conventional Heat	1-1 cph used for steam and gravity. 3-3 cph used for hot water system and high efficiency (90% or better) furnaces 5-5 cph used for standard fossil fuel forced air (less than 80% efficient) systems (factory setting) 9-9 cph used for electric furnaces 2, 4, 6, 7, 8, 10, 11, 12-other cycle rate settings	Not shown if system selection is heat pump.	
0250			NOT USED	
0260			NOT USED	
0270			NOT USED	
0280	Backlight	0-Backlight function disable 1-Backlight function enable	If set to "1", the backlight will illuminate for 10 seconds after any touchscreen press.	
0300	Changeover	0-manual changeover (factory setting) 1-auto changeover		

Table 3. Installer Setup Menu. (CONTINUED)

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0310	Dead band	Heating and cooling set-points can be set no closer than chosen value. 2-2°F (1.5°C) 3-3°F (2°C) 4-4°F (2.5°C) 5-5°F (3°C) 6-6°F (3.5°C) 7-7°F (4°C) 8-8°F (4.5°C) 9-9°F (5°C)	Shown only if automatic changeover is selected.	
0320	Temperature Indication Scale	0-fahrenheit temperature display (factory setting) 1-celsius temperature display	When it is changed, the schedule must be reprogrammed.	
0330	Daylight Savings	1-daylight savings is on (factory setting). 0-daylight savings is off.	Set to 0 in areas that do not follow daylight savings.	

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0340	Remote Temperature Sensor Outdoor or Indoor	0-no remote temperature sensor 1-outdoor temperature sensor for display only 2-can not be select 3-indoor temperature sensor	Defaults and Options depend on System Type selector Indoor Temperature Sensor uses an averaging network and does not include on-board sensor.	
0350			NOT USED	
0360			NOT USED	
0380	Indoor Dehumidification Control		NOT USED	
0500	Filter Change Reminder	0- filter reminder off 1-10 run time days 2-30 run time days 3-60 run time days 4-90 run time days 5-120 run time days 6-365 run time days	Run time based on call for fan.	

A3101 Touchscreen Programmable Thermostat

Table 3. Installer Setup Menu. (CONTINUED)

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0510			NOT USED	
0520			NOT USED	
0530	Adaptive Intelligent Recovery	1-Adaptive Intelligent Recovery control is activated (system starts early so set-point is reached by start of program period). 0-Conventional Recovery (system starts recovery at programmed time)		
0540	Number of Periods	2-two periods available (Wake and Sleep) 4-four periods available (Wake, Leave, Return and Sleep)	Not shown if non-programmable is selected. 2 or 4 applies to all days of the week. When it is changed the schedule must be reprogrammed.	
0580	Minimum Compressor Off Time	5-five-minute compressor off-time setting (factory setting) 0, 2, 3, 4-other compressor off-time settings	Compressor delay is a make signal on all start-up. Display will indicate "Wait" when activated. Recommend Minimum Compressor Off Time. See page 80.	
0600	Heat Temperature Range Stop	40-90-temperature range (1°F increments) of heating set-point.	Shown in 1/2 °C.	
0610	Cool Temperature Range Stop	50-99-temperature range (1°F increments) of cooling set-point.	Shown in 1/2 °C.	
0640	Clock Format	12-12 hour clock (factory setting) 24-24 hour clock		

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0650	Extended Fan On Time Heat	0-0 seconds 30-30 seconds 60-60 seconds 90-90 seconds	Not shown if fan operation is set to "Fan On" or "Cool Only Systems"	
0660	Extended Fan On Time Cool	0-0 seconds 30-30 seconds 60-60 seconds 90-90 seconds	Not shown - Heat Only Systems	
0670	Keypad Lockout	0-unlocked keypad 1-partially locked keypad 2-fully locked keypad	Unlocked all functions are available. Partially locked only. Temperature up and down keys and ability to enter and modify Installer Setup mode are available. Fully locked only ability to enter and modify Installer Setup mode are available.	
0680	Temperature Control in Heat	1-less aggressive temperature control (could cause temperature undershoot) 2-Standard temperature control in heating (factory setting) 3-more aggressive temperature control (could cause temperature overshoot)	Applies to recovery ramp and use of auxiliary heat during recovery. Choose 1 if getting temperature overshoot. Choose 3 if getting temperature undershoot.	

Table 3. Installer Setup Menu. (CONTINUED)

Installer Setup Number	Installer Setup Name	Settings	Notes	Initial Setting Record
0690	Temperature Control in Cool	1-less aggressive temperature control (could cause temperature undershoot) 2-Standard temperature control in cooling (factory setting) 3-more aggressive temperature control (could cause temperature overshoot)	Applies to recovery ramp. Choose 1 if getting temperature overshoot. Choose 3 if getting temperature undershoot.	
0700	Temperature Display Offset	-3°F (-1.5°C) -2°F (-1°C) -1°F (-.5°C) 0°F (0. °C) (no difference in displayed temperature and actual room temperature) 1°F (.5°C) 2°F (1°C) 3°F (1.5°C)		
0710	Reset Thermostat	0-no thermostat reset. 1-resets all Installer Setup Options to default values and resets schedule to default setting.	Only calendar settings and time are retained.	

**CAUTION****Equipment Damage Hazard.****Minimum compressor off time is bypassed during Installer System Test**

Avoid cycling compressor quickly.

How to Use the Installer System Test

The Installer Test is part of the Installer Setup Menu.

1. Enter the Installer System Test by entering the Installer Setup.
2. Note that the test appears at the end of the Installer Setup Numbers.
3. See Fig. 25. to review how the thermostat buttons are used during the Installer System Test. See table 4 (pg 55) for available Installer System Tests.





Fig. 25 Review thermostat buttons used during Installer System Test.

System Test Number	Test Type	System Status Number and Description
Test 1	Cooling System Test	1-Cool stage 1 turn on 2-Cool is off
Test 2	Fan System Test	1-Fan turns on 0-Fan turns off
Test 3	Heating System Test	1-Heat stage 1 turn on 0-Heat is off


Press the Next button to go to the beginning of the Installer Setup or press the Done button to exit the Installer System Test.

USER MANUAL

Thermostat Keys



Thermostat Display



System and Fan Settings

System

The System key selections vary based on your heating and/or cooling system type

HEAT Thermostat controls the heating system.

OFF Both heating and cooling systems are off.

COOL Thermostat controls the cooling system.

AUTO Thermostat automatically changes between heating and cooling operation, depending on indoor temperature.

FAN The Fan key selections vary based on the heating and/or cooling system type.

ON Fan runs continuously. Use this setting for improved air circulation or for more efficient central air cleaning.

AUTO Fan turns off when the temperature is satisfied.



CIRC Fan runs randomly, approximately 35% of the time when there is no call for cooling or heating. Use this setting for improved air circulation or for more efficient central air cleaning when you do not want the fan running continuously.

User Setup

Follow these steps to enter the User Setup:


1. Press and release the SYSTEM key.

2. Press and hold the center blank key for approximately five seconds until the screen changes.




3. Release the center blank key when the screen on the thermostat matches the screen below.

4. See the screen below to see how the thermostat keys are used during the User Setup. See Table 5 for the User Setup numbers and settings.



5. Press the DONE key to exit the User Setup screen.



A3101 Touchscreen Programmable Thermostat

Table 5. User Setup Settings.

Installer Setup Number	Installer Setup Name	Settings
0120	Date (Year Upper)	It cannot be changed.
0130	Date (Year Lower)	Select last two digits of current calendar year (08 for year 2008, etc)
0140	Date (Month)	Select number of current calendar month (1-12)
0150	Date (Day)	Select number of current calendar date (1-31)
0160	Schedule Options	0-Non-programmable 4-7-day programmable(factory setting)(when it is changed, the schedule need to be reprogrammed)
0320	Display temperature in °F or °C	0-°F setting (factory setting) 1-°C setting
0330	Daylight savings time	1-Daylight Savings function is enabled. 0-Daylight Savings is disabled.
0500	Furnace air filter	0-off (factory setting) 1-10 fan run time days(about one month) 2-30 fan run time days(about three months) 3-60 fan run time days(about six months) 4-90 fan run time days(about nine months) 5-120 fan run time days(about one year) 6-365 fan run time days(about three years)
0510		NOT USED
0520		NOT USED

Installer Setup Number	Installer Setup Name	Settings
3540	Number of schedule periods available	2-see WAKE and SLEEP 4-four WAKE DAY EVENING SLEEP factory setting
3640	Clock format	12-12-hour clock(factory setting) 24-24-hour clock
0670	Screen lockout	0-all keys available; screen is unlocked (factory setting) 1-screen is partially locked. All key functions locked except Temperature Up and Down keys and Cancel key. 2-screen is fully locked

PROGRAMMING

Preprogrammed Energy Star Settings

Table 6 shows default program settings. Visit the Energy Star web site at www.energystar.gov for additional education and resources on programmable thermostats.

Table 6. Energy Star Default Program Settings.

Schedule Period	Time	Set-points		Fan Setting
		Heat	Cool	
WAKE	6:00AM	68°F (20°C)	78°F (26°C)	AUTO
DAY	8:00AM	60°F (16°C)	85°F (29°C)	AUTO
EVEING	4:00PM	68°F (20°C)	78°F (26°C)	AUTO
SLEEP	10:00PM	60°F (16°C)	82°F (28°C)	AUTO

Program Heating and Cooling Schedule

Your thermostat can control up to four different schedule periods per day:

WAKE-Period when you awaken and want your home at a comfortable temperature.

DAY-Period when you are away from home and want an energy-saving temperature.


EVENING-Period when you return home and want your home back to a comfortable temperature.

SLEEP-Period when you are asleep and want an energy-saving temperature.

NOTE: Schedule times are in 15 minute intervals.


Edit Schedule

1. Press SCHED key.




2. Press PROG DAY key to review the programs to see that the settings are compatible with your lifestyle.


3. Press the EDIT then you press PROG DAY key to select the program days.



4. Press WAKE key. Once pressed, Wake flashes to show it is selected. Same as the other schedule.



5. Press Up and Down keys to modify time and heat and cool temperatures from this screen.




6. The Fan setting can be programmed for ON, AUTO, or CIRC for each period. Please see Fan Schedule for more information about the Programmable FAN. (see pg 66)

7. To exit schedule without saving changes, press CANCEL key any time.

Cancel a Schedule Period


1. Press SCHED key.
2. Press EDIT key.
3. Select the Day(s) of the week desired.
4. Press schedule period you want to cancel (WAKE, DAY, EVENING or SLEEP). Once selected, the period flashes.




5. Press CANCEL PERIOD key.
6. The time, temperature(s) and fan setting disappear. The bar above the selected period is removed, indicating the scheduled period was cancelled.

NOTE: To reinstate a schedule period, press arrow keys to set desired time and temperatures.

See note 5



ON Fan runs continuously (programmable for all schedule periods).
CIRC Fan runs randomly for approximately 35% of schedule period when there is no call for cooling or heating (programmable for all schedule periods).



7. Press DONE key.

Fan Schedule

(to be programmed during schedule set-up)
 Press FAN key while in the Scheduling Screen to program the System Fan. Choices available from the Scheduling Screen:

AUTO (default position) Fan runs with equipment. Programmable for all schedule

66

Manual Override of Fan Schedule

Use Fan key to change fan mode by pressing fan.

AUTO-fan is automatically following the Fan schedule(choices are Auto, On or Circulate).


ON- Fan runs randomly for approximately 35% of schedule period when there is no call for cooling or heating.

CIRC- Fan circulates randomly for approximately 35% of time.

When the program reaches to next schedule, the fan will run as the setting in the period.

Set Time

1. Press CLOCK key.
2. Use arrows to set current



67


Set Temperature Overrides

The thermostat has three temperature override options: **Override Until**, **Permanent Override** and **Vacation Hold**.

Override Until (TEMPORARY Override)

Holds temperature temporarily until the next scheduled period time or until time is selected.

1. Press the Up or Down arrow below to the temperature you want to adjust. Override Until and set time appears on the screen.
2. Press Up or Down arrow next to the Time to change the time to hold the adjusted temperature setting.



3. If you want to exit Override Until, please press the CANCEL key. Override Until will be also exit until reach the set time.


IMPORTANT

The current day of the week should already be set correctly. If not, see Installer Setup to set the day.

Permanent Override

Keep user set-point permanently.

1. Press HOLD key once. Screen shows Permanent Override.
2. Press Up or Down arrow you want to adjust.




3. If you want to exit Permanent Override, please press the CANCEL key, or press the HOLD key then press the CANCEL key.

Vacation Hold

Change temperature setting for a designated number of days.

1. Press HOLD key twice. Screen shows Override Until and 1 DAYS.
2. Press the Up and Down arrow keys to set the desired temperature while away on vacation. Notice that —Override Until days is shown on the screen. (This is the time the Vacation Hold override expires after the number of day's ends.)
3. Press Up and Down arrow keys to change the number of Days you desire thermostat to override the schedule.




4. To cancel the Vacation Hold override early, press the CANCEL key.

NOTE: When the number of days of Vacation Hold expires, the screen shows Running As SCHED to indicate that Vacation Hold has ended.

Clean Thermostat Screen

The thermostat has a touch screen interaction. Follow these steps to clean the screen without making thermostat parameter changes:

1. Press the SCREEN key. Thermostat locks out all touch keys for 30 seconds to allow for cleaning.



70

2. Use damp cloth slightly moistened with water or household glass cleaner to clean the screen.

3. Repeat the above steps, as necessary.

IMPORTANT


Do not spray any type of liquid directly on the thermostat itself. If using household glass cleaner, spray cleaner on cloth. Then use cloth to clean the thermostat screen.

4. Press the DONE key to return to the Home Screen and normal operation.

Replace Batteries


1. When the Battery indicator is flashing, replace the batteries promptly with two fresh AA alkaline batteries

2. Remove thermostat from the wallplate by pulling straight out.



3. Remove the old batteries and insert two fresh AA alkaline batteries, as marked on the thermostat.

71



4. Align the screw blocks with the pins on the back of the thermostat.


5. Push the thermostat straight onto the wallplate until it snaps into place.

72

Battery Tips

1. Replace the batteries as soon as "Batt" flashes in the display. The Battery indicator flashes in the display one month before the batteries run down completely.
2. Always use fresh AA alkaline batteries. Non-alkaline batteries do not last as long and can leak, causing thermostat damage.
3. Although the thermostat has a Low Battery indicator, replace the batteries once a year to prevent the thermostat and heating/cooling system from shutting down due to lack of battery power.

Screen Locks



Partially Locked Screen

When partially locked, the screen indicates Screen Locked for 5 to 7 seconds whenever the user attempts to press a key that is locked. Pressing a locked key, while Screen Locked is shown, flashes "Screen Locked" on the screen.

In this mode, all keys are locked except the Temperature Up and Down arrow keys: User can change temperature up or down but cannot change schedule settings. Temporary temperature change lasts until next scheduled period and that time shows on screen.

To cancel temperature override and begin following schedule, press CANCEL key. To unlock screen, see Installer Setup section.

Fully Locked Screen



In this mode, all keys are locked and not functional. To unlock screen, see Installer Setup section. The screen continuously displays Screen Locked.

73

Outdoor Temperature

If an outdoor temperature sensor is installed, the thermostat displays the outside temperature in the lower right corner of the Home Screen.

If thermostat is set to Auto Changeover System mode, press the MORE key until the outside temperature is shown on the screen. You can also press MORE key again to check and edit Filter Reminder if the Filter Change Reminder function is chosen.



74

Remote Indoor Temperature


If a remote indoor temperature sensor is installed, the thermostat displays the inside temperature on the screen from the remote sensor(s). The thermostat internal temperature sensor is not used.

ONE REMOTE INDOOR SENSOR INSTALLED (OPTIONAL)

If one remote indoor temperature sensor is used, the screen showing the Inside temperature reading shows the temperature at the indoor remote sensor location. The thermostat internal temperature sensor is not used.

MULTIPLE REMOTE INDOOR SENSORS INSTALLED (OPTIONAL)

If more than one remote indoor sensor is used, the screen showing inside temperature reading shows the average of all the remote indoor sensors. The thermostat internal temperature sensor is not used.




75

Indoor Air Quality Reminders

Filter Change Reminder


The filter change reminder must be turned on from the Installer Setup. Once expired, the screen flashes RENEW FILTER. Press the RESET key to reset the change reminder.



NOTE: The days are counted as fan run time, so anytime the fan is running, the reminder is counting that time against the number of days selected.

The remaining run time days can be viewed by pressing the MORE key; the remaining days can be edited by using the MORE key or from the Installer Setup. To view or reset the reminder by following steps before it expires:


1. Press the MORE key until the filter reminder appears on the screen. This is the number of fan run-time days remaining on the filter reminder.




76

A3101 Touchscreen Programmable Thermostat

2. Press the EDIT key.




3. Use the Up and Down keys to change the number of run-time days.



4. Press the DONE key to go back to the viewing screen.

77

5. Press the RESET key to activate the new number of days selected in the previous screen.



6. Press the DONE key to return to the Home Screen.


78

Temperature Recovery

The thermostat feature, Adaptive Intelligent Recovery, eliminates all guesswork when setting the thermostat schedule. Simply set the program schedule to the time that the comfort temperature is desired. The thermostat then turns on the heating or cooling at just the right time to have the home reach the scheduled temperature at the scheduled time.

For example get up at 6:00 AM and want the temperature to be 70°F. Set the Wake period for 6:00 AM and 70°F. The thermostat then turns on the heat before 6:00 AM to raise the temperature to 70°F by 6:00 AM.

The thermostat alerts that the heating or cooling system to turn on before a scheduled time by showing Recovery on the screen.




79

Minimum Off-Timer

The Thermostat has built-in compressor protection (minimum-off timer) that prevents the compressor from restarting too early after a shutdown.

The minimum-off timer is activated after the compressor turns off.

If there is a call or set point change during the minimum-off timer, the thermostat shows Wait in display.



80

Special Heat Pump Operation Heat Pump Indication (Requires 24VAC Common Connection)

"E5" indication is located in the screen of the thermostat. It is only visible when lighted. When the L terminal is wired to an equipment monitor, this is operational in the HEAT, OFF, COOL or AUTO positions. When the "E5" is illuminated call for service. See Fig. 26.




Fig. 26. L terminal switch to R (power) side of system transformer.

Operating Sequence

The thermostat energizes specific terminal(s), depending on the demand for heating, cooling or fan. The thermostat screen shows the time, inside temperature, system and fan selections. Additional indicators are shown when the heating, cooling or fan is energized. See Tables 7 - 9 for specification information.

81

Table 7. Sequence of Operation for Conventional Systems.

System Setting	Fan Setting	Call for Action	Energize Terminals	Screen Message
OFF	AUTO	None	None	None
COOL	AUTO	None	None	None
COOL or AUTO	AUTO	Stage 1 Cooling	Y, G	Cool On
COOL or AUTO	AUTO	Stage 1 Cooling	Y, G	Cool On
HEAT	AUTO	None	None	None
HEAT or AUTO	AUTO	Stage 1 Heating	W, G ^a	Heat On
HEAT or AUTO	AUTO	Stage 1 Heating	W, G ^a	Heat On

G^a energizes only if Installer Setup number 0180 is set to Electric.

Table 8. Sequence of Operation for Power Open and Power Closed Valves or Normally Open Valves.

System Setting	Fan Setting	Call for Action	Energize Terminals	Screen Message
OFF	AUTO	None	None	None
HEAT	N/A	None	Y	None
HEAT	N/A	Heat	W	Heat On

82

Table 9. Sequence of Operation for Heat Pump Systems.

System Setting	Fan Setting	Call for Action	Energize Terminals	Screen Message
OFF	AUTO	None	O/B ^a	None
COOL	AUTO	None	O/B ^a	None
COOL or AUTO	AUTO	Stage 1 Cooling	Y, G, O/B ^a	Cool On
HEAT	AUTO	None	O/B ^a	None
HEAT or AUTO	AUTO	Stage 1 Heating	Y, G, O/B ^a	Heat On

^a Configure O/B in Installer Setup (cooling = O or heating = B).

83

Outdoor Temperature Sensor Operation

When installed with Thermostat Installer Setup Number 0340 set to 1 or 2, the outside temperature can be displayed on the thermostat. See Fig. 27.




Fig. 27. Outside temperature reading on A3101 Thermostat.

The Outdoor Sensor converts outdoor ambient temperature to a resistance that the thermostat can interpret.

The sensor has a negative temperature coefficient (NTC), which means that resistance decreases as the temperature increases.

Checkout

With an accurate thermometer ($\pm 1^\circ\text{F}$ [0.5°C]) measure the temperature at the sensor location, allowing time for the thermometer to stabilize before reading.

Calibration

The Outdoor Sensor is calibrated at the factory and cannot be recalibrated in the field.

84

Remote Indoor Temperature Sensor Operation

When installed with Thermostat Installer Setup Number 0340 set to 3, the remote inside temperature is displayed on the Thermostat Home Screen as Inside Temperature. The thermostat internal temperature sensor is not used. See Fig. 28.




Fig. 28. Inside temperature reading on A3101 Thermostat.

A3101 Touchscreen Programmable Thermostat

The Wall Mount Temperature Sensor converts room temperature to a resistance that the thermostat can interpret.

The sensor has a negative temperature coefficient (NTC), which means that resistance decreases as the temperature increases.

The sensor can be used to provide one remote sensor input (see Fig. 23) or as a temperature averaging network with multiple Sensors connected, as shown in Fig. 24

Checkout

For best results, allow Wall Mount Temperature Sensor to absorb the air moving through the room for a minimum of twenty minutes before taking a resistance measurement.

With an accurate thermometer ($\pm 1^\circ\text{F}$ [0.5°C]) measure the temperature at the sensor location allowing time for the thermometer to stabilize before reading.

Calibration

The Wall Mount Temperature Sensor is calibrated at the factory and cannot be recalibrated in the field.

85

TROUBLESHOOTING (TABLE 10)

Table 10. Troubleshooting.

Symptom	Possible Cause	Action
Display does not come on.	Thermostat is not being powered.	Check for 24VAC between C and RC. Check that AA batteries are installed correctly and are good.
Temperature settings do not change.	The upper or lower temperature limits were reached.	Check temperature set-points. Check Installer Setup Numbers 0600 and 0610; modify as needed.
	The keypad is fully locked.	Check Installer Setup Number 0670 to change keypad locked options.
Heating or cooling does not come on.	Thermostat minimum off-time is activated.	Wait up to five minutes for the system to respond.
	System selection is not set to Heat or Cool.	Set system Selection to correct position.
	System type Selection is incorrect.	Check Installer Setup Number 0170 and make sure correct System type is chosen.
Thermostat is calling for Heat (Heat on) or Cool (Cool on) but no heating or cooling is running.	Heating or cooling equipment is not operating.	Check wiring. Check Installer Setup Number 0170 and make sure correct system type is chosen. Verify operation of equipment in System Test mode.

Table 10. Troubleshooting. (CONTINUED)

Symptom	Possible Cause	Action
Heat does not turn on (Heat On is solid in the display).	Heating equipment failure.	Check for 24VAC at the equipment on the secondary side of the transformer between power and common. If voltage is not present, check the heating equipment to find the cause of the problem. Check for 24VAC between the heat terminal (W) and transformer common. If 24VAC is present, the thermostat is functional. Check the heating equipment to find the cause of the problem.
	Loose or broken wire connection between thermostat and heating equipment.	Check for 24VAC between the heat terminal (W) and transformer common. If voltage is not present, check wire connection (loose or broken) between the thermostat and the heating equipment.
Cooling does not turn on (Cool On is solid in the display)	Cooling equipment failure.	Check for 24VAC at the equipment on the secondary side of the transformer between power and common. If voltage is not present, check the cooling equipment to find the cause of the problem. Check for 24VAC between the cool terminal (Y) and transformer common. If 24VAC is present, the thermostat is functional. Check the cooling equipment to find the cause of the problem.

Table 10. Troubleshooting. (CONTINUED)

Symptom	Possible Cause	Action
Cooling does not turn on (Cool On is solid in the display).	Loose or broken wire connection between thermostat and cooling equipment.	Check for 24VAC between the cool terminal (Y) and transformer common. If voltage is not present, check the wire connection (loose or broken) between the thermostat and the cooling equipment.
Fan does not turn on in a call for heat (electric furnace).	Fan Control in Heating is set to Gas or Oil Furnace (Setting 0180).	Set Fan Control in Heating to Electric Furnace (Setting 0180).
Heat pump puts out cool air in the heat mode and warm air in the cool mode.	Changeover Valve (Installer Setup Number 0190) is not configured to match the changeover required by the installed heat pump.	Set Changeover Valve (Installer Setup Number 0190) to match the changeover required by the installed heat pump.
Both the heating and cooling equipment are running at the same time.	The heating equipment is not a heat pump but the System Type (Installer Setup Number 0170) is set to Heat Pump.	Set System Type (Installer Setup Number 0170) to match the installed heating and/or cooling equipment.
	Heating and cooling wires are shorted together.	Separate the shorted heating and cooling wires.
Heating equipment is running in the cool mode.	Heating equipment is not a heat pump but System Type (Installer Setup Number 0170) is set to Heat Pump.	Set System Type (Installer Setup Number 0170) to match the installed heating and/or cooling equipment.
Heating equipment does not turn off and heat temperature setting is set below room temperature (Heat On is not in the display).	Heating equipment is not a heat pump but System Type (Installer Setup Number 0170) is set to Heat Pump.	Set System Type (Installer Setup Number 0170) to match the installed heating and/or cooling equipment.

88

Table 10. Troubleshooting. (CONTINUED)

Symptom	Possible Cause	Action
Cannot set the system setting to Heat.	System Type (Installer Setup Number 0170) is set to Cool Only.	Set System Type (Installer Setup Number 0170) to match the installed heating and/or cooling equipment.
Cannot set the system setting to Cool.	System Type (Installer Setup Number 0170) is set to Heat Only or Heat Only with Fan.	Set System Type (Installer Setup Number 0170) to match the installed heating and/or cooling equipment.
Heat On is not in the display.	System setting is not set to Heat and/or temperature setting is not set above room temperature.	Set the system setting to Heat and set the temperature setting above the room temperature.
Cool On is not in the display.	System setting is not set to Cool and/or the temperature setting is not set below room temperature.	Set the system setting to Cool and set the temperature setting below the room temperature.
Wait is in the display.	Compressor minimum off timer is active.	Wait up to five minutes for the cooling or heating (heat pump) equipment to turn on.
Screen Locked appears on the screen and all or some of the keys do not respond.	The keypad is fully or partially locked.	Check Installer Setup Number 0670 to change keypad locked options.

89